




User Manual

METERS & ELECTRONICS
COIMBATORE

ATSGA Automatic Transfer Switch

ATSQ1JA 100A, 160 A, 250 A





INDEX

1. Types and Meanings
2. Main Technology Parameters
3. Products Structure Instruction
4. Outline Overall and Installing Dimensions
5. Usage Method
6. Method of Terminal Connection
7. Correct installation method for Switch
8. Wiring Methods of Switch
9. Note of Debug Switch

ATSGA Automatic Transfer Changeover-Switch

1. Types and Meanings




2. Main Technology Parameters

According to the Standard: IEC 60947-2-1

| | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--------|------|------|------|------|-------|-------|-------|-------|-------|-------|-------|------|--|--|--|--|--|--|--|--|--|--|--|
| Rated Current Ist | 100A | 160A | 250A | 400A | 630A | 800A | 1000A | 1250A | 1600A | 2000A | 2500A | 3200A | | | | | | | | | | | | |
| Rated Isolation Voltage Ui | 750V | | | | | | | | | 1000V | | | | | | | | | | | | | | |
| Rated Shock Withstand Voltage Uimp | 8KV | | | 12KV | | | | | 12KV | | | | | | | | | | | | | | | |
| Rated Working Voltage Ue | AC400V | | | | | | | | | | | | | | | | | | | | | | | |
| Rated Working Current le | AC-31A | 100 | 160 | 250 | 400 | 630 | 800 | 1000 | 1250 | 1600 | 2000 | 2500 | 3200 | | | | | | | | | | | |
| | AC-35A | 100 | 160 | 250 | 400 | 630 | 800 | 1000 | 1000 | 1600 | 2000 | 2500 | 3200 | | | | | | | | | | | |
| | AC-33A | 100 | 160 | 250 | 400 | 400 | 630 | 800 | 800 | 1000 | 2000 | 2500 | 3200 | | | | | | | | | | | |
| Rated Making Capability | 10le | | | | | | | | | | | | | | | | | | | | | | | |
| Rated Breaking Capability | 8le | | | | | | | | | | | | | | | | | | | | | | | |
| Rated Limited Short-Circuit Current | 50KA | | 70KA | | | 100KA | | 120KA | | | | | | | | | | | | | | | | |
| Rated Short-time Withstand Current 1s | 7KA | 9KA | 13KA | 26KA | 50KA | | | | 55KA | | | | | | | | | | | | | | | |
| Change-over Time I - II or II - I | 0.6S | | 0.6S | | 1.2S | | | 1.8S | | 1.2S | | | | | | | | | | | | | | |
| Control Power Supply Voltage | AC220V | | | | | | | | | | | | | | | | | | | | | | | |
| Power Consumption of Electrical Machine | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated Control Power | Start | 325W | | 355W | | 400W | | 440W | | 600W | | | | | | | | | | | | | | |
| | Normal | 62W | | 74W | | 90W | | 98W | | 120W | | | | | | | | | | | | | | |
| Weight (kgs) | 4Pole | 6.0 | 6.0 | 7.6 | 15.8 | 16.8 | 36 | 36 | 37 | 38.6 | 55 | 61 | 67 | | | | | | | | | | | |


3. Instruction of Structure



- 1、Electric key lock:Control switch inside controlling line power supply,when the electric lock open,the switch could be operated automatically and remotely,then the electric lock closed,the switch could be only operated by handle.
- ★ 2、Operating handle:When operate the switch by operating handle,the electric lock must be closed.
- 3、Mechanic padlock:When inspection,firstly the switch turned into the position of 0 by operation handle,then pull the padlock mechanism and close the padlock,then the inspection could be arranged:(Pull the mechanism padlock will cut off the inside controlling power supply of the switch.The switch couldn't be in electromotion position and also couldn't be manual drive.
- 4、Position indication:Indicate the position of the switch working estate(I,0,II)
- 5、Controlling voltage:Switch controlling voltage grade 220VAC
- 6、Switch main body:The front part is I line,connecting to "Normal power";the rear Part is II line,connecting to "Emergency power."

Dual Power Automatic Transfer Switch

4. Installing Dimensions




| Spec. | Dimension | | | | | | | | | | | | | | | | | | | | | | |
|---------------|-----------|-----|-----|-----|-----|-----|-----|----|-----|-----|----|----|-------|-----|----|----|-----|-----|----|----|------|-----|----|
| | In | A | A1 | B | B1 | C | E | G | H | J | K | L | N | O | P | R | S | T | U | V | φX | Y | Y1 |
| 100A/3 | 235 | 232 | 106 | 105 | 150 | 140 | 115 | 19 | 222 | 84 | 7 | 83 | 142.5 | 30 | 14 | 18 | 2.5 | 103 | 13 | 6 | 41.5 | 93 | 2 |
| 100A/4 | 280 | 244 | 107 | 105 | 150 | 140 | 115 | 19 | 226 | 84 | 7 | 83 | 142.5 | 30 | 14 | 18 | 2.5 | 103 | 13 | 6 | 41.5 | 93 | 2 |
| 160A/3 | 292 | 270 | 140 | 142 | 213 | 200 | 145 | 10 | 254 | 117 | 7 | 93 | 192 | 36 | 20 | 25 | 3.5 | 127 | 21 | 9 | 55.5 | 127 | 4 |
| 160A/4 | 360 | 303 | 140 | 142 | 213 | 200 | 145 | 10 | 285 | 117 | 7 | 93 | 192 | 36 | 20 | 25 | 3.5 | 127 | 21 | 9 | 55.5 | 127 | 4 |
| 250A/3 | 356 | 312 | 170 | 142 | 216 | 208 | 145 | 6 | 293 | 103 | 7 | 93 | 250 | 50 | 25 | 28 | 3.5 | 141 | 29 | 11 | 58 | 131 | 9 |
| 250A/4 | 420 | 362 | 180 | 142 | 216 | 208 | 145 | 6 | 343 | 103 | 7 | 93 | 250 | 50 | 25 | 28 | 3.5 | 141 | 29 | 11 | 58 | 131 | 9 |
| 400A/3 | 530 | 370 | 270 | 222 | 286 | 275 | 245 | 20 | 365 | 179 | 9 | 97 | 268 | 65 | 32 | 37 | 5 | 222 | 38 | 11 | 83 | 193 | 6 |
| 400A/4 | 590 | 440 | 270 | 222 | 286 | 275 | 245 | 20 | 425 | 179 | 9 | 97 | 328 | 65 | 32 | 37 | 5 | 222 | 38 | 11 | 83 | 193 | 6 |
| 630A/3 | 530 | 370 | 270 | 222 | 286 | 275 | 245 | 20 | 365 | 179 | 9 | 97 | 268 | 65 | 40 | 45 | 6 | 222 | 38 | 11 | 83 | 193 | 14 |
| 630A/4 | 590 | 440 | 270 | 222 | 286 | 275 | 245 | 20 | 425 | 179 | 9 | 97 | 328 | 65 | 40 | 45 | 6 | 222 | 38 | 11 | 83 | 193 | 14 |
| 800~1000A 3P | 785 | 520 | 380 | 250 | 351 | 340 | 360 | 20 | 503 | 220 | 11 | 88 | 415 | 120 | 60 | 64 | 8 | 250 | 59 | 13 | 109 | 254 | 39 |
| 800~1000A 4P | 1080 | 634 | 380 | 250 | 351 | 340 | 540 | 20 | 613 | 220 | 11 | 88 | 529 | 120 | 60 | 64 | 8 | 250 | 59 | 13 | 109 | 254 | 39 |
| 1250~1600A 3P | 785 | 520 | 380 | 250 | 351 | 340 | 360 | 20 | 503 | 220 | 11 | 88 | 415 | 120 | 80 | 68 | 8 | 250 | 59 | 13 | 110 | 255 | 43 |
| 1250~1600A 4P | 1080 | 634 | 380 | 250 | 351 | 340 | 540 | 20 | 617 | 220 | 11 | 88 | 529 | 120 | 80 | 68 | 8 | 250 | 59 | 13 | 110 | 255 | 43 |
| 2000A/3 | 785 | 535 | 423 | 560 | 360 | 408 | | | | 490 | | 80 | 81 | 10 | | 30 | | | | | | 113 | |
| 2000A/4 | 1080 | 650 | 423 | 560 | 540 | 523 | | | | 605 | | 80 | 81 | 10 | | 30 | | | | | | 113 | |
| 2500A/3 | 785 | 535 | 433 | 560 | 360 | 408 | | | | 490 | | 80 | 81 | 15 | | 30 | | | | | | 118 | |
| 2500A/4 | 1080 | 650 | 433 | 560 | 540 | 523 | | | | 605 | | 80 | 81 | 15 | | 30 | | | | | | 118 | |
| 3200A/3 | 785 | 535 | 443 | 560 | 360 | 408 | | | | 490 | | 80 | 81 | 20 | | 30 | | | | | | 123 | |
| 3200A/4 | 1080 | 650 | 433 | 560 | 540 | 523 | | | | 605 | | 80 | 81 | 20 | | 30 | | | | | | 123 | |


Dual Power Automatic Transfer Switch

5. Usage Method

5.1 100A Type Wiring



5.2 Automatic Control Wiring



102:A Phase of Normal Power Source

103:N Phase of Normal Power Source

104:A Phase of Backup Power Source

105:N Phase of Backup Power Source

201 202 203 204 205 206


201+206 means Automatic Working Mode

Dual Power Automatic Transfer Switch

- HL 1(102+103) is the indicator to show the Normal Power has electricity or not
- HL 2(104+105) is the indicator to show the Backup Power has electricity or not
- HD 1(302+303) is the indicator to show the ATS is working at the Normal Power side
- HD 2(302+305) is the indicator to show the ATS is working at the Backup Power side
- FU 1 and FU 2 are the 2A fuses
- 401-406, 501-506 are the reserved terminals to customize special functions extra

5.3 Automatic Control +Both Off Working Mode


(Both power source are disconnected)



Dual Power Automatic Transfer Switch


- HL 1(102+103) is the indicator to show the Normal Power has electricity or not
- HL 2(104+105) is the indicator to show the Backup Power has electricity or not
- HD 1(302+303) is the indicator to show the ATS is working at the Normal Power side
- HD 2(302+305) is the indicator to show the ATS is working at the Backup Power side
- FU 1 and FU 2 are the 2A fuses
- 401-406, 501-506 are the reserved terminals to customize special functions extra

5.4 Automatic + Manual (Remote Control) Wiring




102:A Phase of Normal Power Source
103:N Phase of Normal Power Source
104:A Phase of Backup Power Source
105:N Phase of Backup Power Source

201+206 means Automatic Working Mode
202+203 means Remote Manu Control to work at Normal Power Source
202+204 means Remote Manu Control to work at Backup Power Source




- HL 1(102+103) is the indicator to show the Normal Power has electricity or not
- HL 2(104+105) is the indicator to show the Backup Power has electricity or not
- HD 1(302+303) is the indicator to show the ATS is working at the Normal Power side
- HD 2(302+305) is the indicator to show the ATS is working at the Backup Power side
- FU 1 and FU 2 are the 2A fuses
- 401-406, 501-506 are the reserved terminals to customize special functions extra

5.5 For Remote Manual Control Wiring




- HL 1(102+103) is the indicator to show the Normal Power has electricity or not
- HL 2(104+105) is the indicator to show the Backup Power has electricity or not
- HD 1(302+303) is the indicator to show the ATS is working at the Normal Power side
- HD 2(302+305) is the indicator to show the ATS is working at the Backup Power side
- FU 1 and FU 2 are the 2A fuses
- 401-406, 501-506 are the reserved termials to customize special functions extraly

6. Method of terminal connection



Use the screw driver use force downwards as the picture indicated direction, the line imbedding as the picture shows.

7. Correct installation method for switch



(A) (B) (C) correct (D) incorrect

8.wiring methods of switch

(Please refer to the right installation method for switch A)

- 1.The switch from left to right,I and II connection copper lines connected with normal power (front) and emergency power(behind) respectively with A,B,C phases
- 2.Controlling power origin from normal power and emergency power respectively with C and N phases.
- 3.I and II line controlling power AC220V connected with terminal 102~103,104~105 respectively,therein 102 and 104 are normal power and emergency power live line respective.
- 4.Terminal 101,106 are act as signal lamp to control power supply,therein 106 is the live line. Note:101 and 106 couldn't be connected with any other lines.
- 5.When above(under) input line,above(under)terminal I and II line A,B,C phases will be connected with copper lines or lines acting as output.

9. Note of debug switch

1.Connect the normal power(I),emergency power(II) with the corresponding connecting board copper lines respectively;

①Automatic debugging

Normal power supply with electric,emergency power supply with electric,switch I line switch on

Normal power supply without electric,emergency power supply with electric,switch II switch on

Normal power supply with electric,switch I line switch on
(Refer to the switch panel white indicating arrowhead)

②Remote debugging

Press bush putton SB1,then the switch I line switch on

Press bush putton SB2,then the switch II line switch on

③Automatic/Remote(handle)debugging

When dial the function selection switch into the automatic position: the switch should act according to the ① item requirement;when dial the function selection switch into the remote (handle) position: the switch should act according to the ② item requirement;

- 2.When the switch in the position of switch on I line or II line,the signal lamp on the panel should indicate correspondingly.
- 3.After finished the debugging,close the power supply firstly, and circumgyrate the switch into "0 position" by handle.(Middle position, refer to the switch panel white indicating arrowhead).